The Stat Summary report that comes with QC-CALC only displays columns for some statistical values, but there are other values available to be displayed. This White Paper will give step by step instructions for customizing the default template and changing the "Sigma" column to show the "Percent Out of Spec" instead.

The Report Designer

The directions shown here will change the "Sigma" column to "Percent OOS" instead. This is a lengthy process, but relatively simple to accomplish.

1. From QC-CALC Real-Time choose the Report – Design Template menu.



2. Choose the StatSum.STT template from the list of files that appears and click **Open**. The Report Designer now appears on the screen.



Header Lines

1. Double click on the table and the Table Contents window will appear.

Table Contents Header Line Data Line	✓ Foote	er Line	✓ Group Heade	r Gr	oup Footer
 Line Definition 1 Dimension Label" "" "Nom + Tol \ -Tol" " "Average" "Kange" "Kange" "Nax" "Min" "Sigma" cond(displayPpk,"Pp","Cp") cond(displayPpk,"Cpk","Cpk") cond(displayPpk,"Cpk","Cpk R") 	Ŷ ¥	 Design Name Data (Conte Option Appea Backgri Export Font Formar Rotation Text Formar Action Link UI Layout Alignn Appea Design 	[+] ents) as picture t born RL t nent rance Condition	Pattern/Blo No None O° Normal Text	Color [Arial 9.0 pt]
P -			E	ОК	Cancel

- 2. On the **Header Line** tab, choose the "Sigma" line on the left and click the F2 button to edit that value. Enter "Percent OOS" as the new column heading value and click Enter.
- 3. Now that you've fixed the column heading, let's change the values that will be displayed below the heading. On the **Data Line** tab choose the same line you choose on the **Header Line** tab. It is hard to read the contents of the lines, so counting the number of lines is easier.

1	Header Line 🖌 🖌 Foote	r Line 🖌 Group Heade	r Group Footer
	🕺 🕈 📲 🗙 🎽 🛍 🕯 🦊	▲ [+]	0
	Line Definition 1 A FStr\$(Dimension."###")	Design Name	
	if(StrPos(Label, "?")=-1,Label,Left\$(Label,StrPos((Contents)	if(Upper\$(DimensionS
	if(Upper\$(DimensionSource)="P/F","Pass/Fail", A "		-
	if(Upper\$(DimensionSource)="P/F"," ",FStr\$(Me (A) if(Upper\$(DimensionSource)="P/F"," ",FStr\$(Ra)	Export as Picture	No
	if(Upper\$(DimensionSource)="P/F"," ",FStr\$(Mz if(Upper\$(DimensionSource)="P/F"," ",FStr\$(Mi)	Font Format	[Arial 8.0 pt] None
	A if(liner\$(DimensionSource)="D/F" " if(No V)	Rotation Text Format	0° Normal Text
	If (Upper) (UimensionSource) = "P/F" . or. Toll ype If (Upper) (UimensionSource) = "P/F" . or. Toll ype If (Upper) (UimensionSource) = "P/F" . or. Toll ype	Action Link URI	
	A if(UpperStormensionSource) = P/F .or. ToType A if(UpperStormensionSource) = "P/F"," ",if(No_Va	□ Layout	
	if(Upper\$(DimensionSource)="P/F".or. 1011ype if(Upper\$(DimensionSource)="P/F".or. ToIType	Alignment Appearance Condition	Always Show
		Design	

- 4. Double-click that line and the **Edit Table** screen appears.
- 5. In the **Edit Table** screen the line showing at the bottom of the screen has a value that needs to be changed. The "Standard_Deviation" shown in the picture below needs to change to:

ical functions matical functions functions functions unctions pate functions e
rical functions matical functions inctions iunctions unctions jate functions e functions e functions
ical functions matical functions inctions iunctions unctions jate functions e functions e functions
matical functions Inctions functions Jate functions e functions e functions e functions e functions
Inctions functions unctions Jate functions e functions functions
functions unctions jate functions 'e functions
unctions Jate functions le functions
yate functions le functions
e functions
vien functions
Sion functions
ce [°] [FStr5(Standard_Deviation," [•] [•] [•] - [*] ,"+Rep5("#",Pro
ر ريا ا

Per_over_USL+Per_under_LSL

6. Now that the value being used is what you want, you need to fix the formatting (since a percentage is displayed differently than a Sigma value).

Variables and Functions Condition Text	Date Format Number Format Operators	
Preventure P	Functions:	
Example: Rep\$("+",5) -> "+++++"		
rce)="P/F'," ',if(No_Variance,"No Varian	nce',FStrS <mark>Per_over_USL+Per_under_LSL,"&."+Rep</mark> S("#',Precision	

7. To fix the formatting the "----&."+Rep\$("#", Precision+2) section of the line needs to be changed. Enter "##&.##%" in place of the text above (make sure you remove the ")" at the end too) to allow 3 places to the left of the decimal and 2 to the right followed by a % sign.

variables and Functions Cond	ition Text Date Format Number Format Operators	
	Functions:	
+ 🔯 Variables		7
+ m User variables	🗉 🫅 Numerical functions	4
	🕀 🧰 Mathematical functions	
	i 🛅 Date functions	=
	🗄 🧰 String functions	
	Generate functions	
	Aggregate functions	
	Conversion functions	-
		<u>I</u> nsert
ionSource)="P/F',"',if(No_V	ariance, "No Variance', FStr\$(Per_over_USL+Per_under_LS(, "##&.##%")))	
		() (
		() (Σ _Σ Δ
		(tt) (m) Σ _Σ Δ
щ		(;;;) (m Σ _Σ ()
No Variance		 (±±) (±±) (±) (±)

- 8. When you've finished the area in the **Edit Table** screen that shows "No Variance" in the picture above should NOT show an error. If it does, make sure you have 3 ")" at the end of the line as that is the most common issue.
- 9. Click the **OK** button on both the **Edit Table** and **Table Contents** windows and save your changes to the template.
- 10. When you run your report you will now have a column called "Percent OOS" that shows the percentage of points that were out of spec for each dimension.