


Reporting – Entering a Value at Report Time

There are times you would like to have values entered into your reports but you do not need those values stored along with your data. Commands can be added within your template to collect typed values at run-time. There are two ways to be asked for this information (type the value into the **Print Preview** screen or have a question pop up and wait for an answer) and both methods will be covered here.


Common Steps

These steps need to be followed for either method. After completing these steps, proceed to the correct section for instructions for the method you are choosing to use.

1. From QC-CALC Real-Time choose the **Report – Design Template** menu.




2. Choose the DataStat.raw template from the list of files that appears and click **Open**.
3. The Report Designer now appears on the screen.





Reporting – Entering a Value at Report Time

4. Choose **Objects – Insert – Form Control** for the [Fill in the Blank Method](#) on page 2 or **Objects – Insert – Text** for the [Ask Method](#) on page 5 from the Report Designer.
5. The cursor will now change to a target which you will use to draw a rectangle object below the gray title bar in the upper right corner of the screen.



6. If you are using the Ask Method and inserted a Text object, please continue to the [Ask Method](#) section, then return to this area to finish the remaining general steps.
7. The next step is to make the box so that it only appears on the first page of the report. To do this right click on the object and choose **Assign to Layer**.



8. In the **Choose a Layer** box, choose the **First Page** layer and click **OK**. You will notice that the rectangle that you previously drew is now green.


Fill in the Blank Method

The directions shown here will customize the Form Control object added in the previous steps in the Raw Data template. This object shows a box on the report where the operator can fill in the Customer Name. The drawback to this method is that using either **Print Preview** or **Print To - File** (PDF only) is required. If you print directly to the printer the operator will never see the box in order to fill in the value.



1. Now that you have inserted the Form Control object and assigned it to the correct layer, these are the instructions for making any changes to that specific item.
2. The **Properties** area in the lower left corner of the screen (**View – Windows – Property Window** will turn on this area if you do not see this it) is used to control how the text the operator types in on the report will look. The directions here will make the text the operator types in be right justified, 12 pt, and red in color.

Reporting – Entering a Value at Report Time



- In the **Appearance** section of the **Properties** area choose “Right” for the **Alignment** option to make the text displayed as right justified.



- In the **Appearance – Font** section first click the + sign to the left of the **Font** property to see all the options within the Font area.
- Set the **Default** value to “No” which will enable you to edit different properties of the font to display.



- Now choose **Size** and choose “12 pt” in the list that appears by hitting the down arrow button.
- The last step for the font is to change the font color to **red**. To do this click the down arrow button and choose the “LL.Color.Red” item in the list as shown in the picture above on the right.
- By default the box will appear with a frame around it. To remove this frame, click on the **Appearance – Border** item and set it to “Transparent”.
- In the **Design** area type “Customer Name” for the **Name** item. This will make any messages that are shown to the operator clearer.
- In order to make your users enter a value you also need to change the **Force Input** option in the **Data** area to “Yes”. There are a few other settings in this area that you may find useful for your specific application too.



- Now choose **File – Save** and **File – Exit**.

Reporting – Entering a Value at Report Time

- You will be asked if you changed the number of dimensions in the report, click **No**.
- Now use the **Report – Print Report** menu and choose the template you just changed along with the **Printer** and **Print Preview** option before clicking the **Print** button.
- The Print Preview will appear next. In the upper right corner there is a red box which is the box for the operator to type the Customer Name value into.

- Type the Customer Name into the box and print out your results. The blue line displayed around that area is not printed. It is shown so that the text areas are still visible after values have been entered.

June 4, 2015
1:50:27 PM

ABC Company, Inc.


- If you print directly to a PDF file and choose the **Open in Default Application** option you will see a blue rectangle where the Customer Name can be entered. The red font does not appear to be saved, but you are able to enter the value. If you want to have your report in .pdf format AND the red font you will need to choose **Print Preview**, then from the Print Preview screen use the **Save As** button. Follow the steps there and the .pdf will be created with the Customer Name included in red.

Reporting – Entering a Value at Report Time


Ask Method

The directions shown here will modify the Text object inserted using the **Objects – Insert – Text** step in the Common area to use an **AskString\$** command. This AskString\$ command will pop a question when the report runs and ask the operator to enter the Customer Name for this report. This method will ask for the value if the report is being printed directly to the printer, to Print Preview, or to a file.

1. After drawing the Text object the **Edit Text** window will automatically be displayed for you.
2. On the **Variables and Functions** tab, choose “AskString\$(..” from the **Misc. functions** list in the **FUNCTIONS** area on the right, and click the **Insert** button.



3. This will insert the AskString\$ function into the blank area at the bottom of the screen.




4. Once the function has been inserted the cursor will be on the AskString\$ line and it will be waiting for you to enter the prompt to display to the user at run time. “Enter the Customer Name” was entered in the example above.
5. Once the cursor has been moved to the location after the next comma, you will be prompted for the next parameter. Enter False as the next parameter so the Customer Name entered for the first page of the report will be used for all pages.

Reporting – Entering a Value at Report Time


The remaining parameters of the AskString\$ function will not be used which means the remaining commas need to be deleted from the line. When you have finished the line should read:

```
AskString$("Enter the Customer Name",False)
```


and the syntax error at the bottom of the screen should be gone.



6. Click **OK** to finish in the **Edit Text** window.
7. That finishes the mechanism that will ask the question, now we need to control how the answer will be displayed in the report. The directions here will make the text the operator types in be right justified, 12 pt, and red in color.
8. Double-click on the gray box you drew in the upper right corner (it should now show "<UserInput>" inside the box. This will bring up the **Paragraph Properties** screen.
9. With the "AskString\$" line highlighted on the left side of the **Paragraph Properties** window, choose "Right" in the **Layout – Alignment** area to make the text display as right justified.




17. In the **Appearance – Font** section first click the **+** sign to the left of the **Font** property to see all the options within the Font area.
18. Set the **Default** value to "No" which will enable you to edit different properties of the font to display.
19. Now choose **Size** and choose "12 pt" in the list that appears by hitting the down arrow button.




Reporting – Entering a Value at Report Time


20. The last step for the font is to change the **Font – Color** to **red**. To do this click the down arrow button and choose the “LL.Color.Red” item in the list.



21. Click **OK** in the **Paragraph Properties** window.
22. Now choose **File – Save** and **File – Exit**.
23. You will be asked if you changed the number of dimensions in the report, click **No**.
24. Now use the **Report – Print Report** menu and choose the template you just changed along with the **Printer** and **Print Preview** option before clicking the **Print** button.
25. The Print Preview will appear next. In the upper right corner there is a red box which is the box for the operator to type the Customer Name value into.
26. You will now be prompted to enter the Customer Name.



27. Replace the text in the **User Input** box with the customer name.



Reporting – Entering a Value at Report Time

28. Once you have typed in the answer, click the **OK** button and “ABC Company, Inc.” will be shown on the report. Here is an example shown in the **Print Preview** window.

The screenshot shows a software window titled "Preview" with a toolbar at the top. The main content area displays a "Raw Data Report" for "Prolink, Inc." The report includes a header with the date "June 5, 2015" and time "11:57:22 AM". A red box highlights the text "ABC Company, Inc." in the top right corner of the report area. The report contains a table with columns for "Rec Num", "X Hole Position", "Y Hole Position", "Z Hole Position", "Line Length", "Datum 1", "Datum 2", "Datum 3", "Datum 1 - Datum 2", "Chamber Angle", "Snap Dis", "Date", and "Time". The table lists various data points for different records, including statistical values like Mean, Max, Min, Range, Sigma, Pp, and Ppk, followed by individual record data from record 76 to 93.

Rec Num	X Hole Position	Y Hole Position	Z Hole Position	Line Length	Datum 1	Datum 2	Datum 3	Datum 1 - Datum 2	Chamber Angle	Snap Dis	Date	Time
Nominal	1.0000	2.0000	3.0000	4.0000	5.0000	6.0000	7.0000	8.0000	9.0000	10.0000		
USL	1.0010	2.0020	3.0030	4.0040	5.0050	6.0060	7.0070	8.0080	9.0090	10.0100		
LSL	0.9990	1.9980	2.9970	3.9960	4.9950	5.9940	6.9930	7.9920	8.9910	9.9900		
Mean	0.9993	1.9984	2.9979	3.9975	4.9976	6.0011	7.0020	7.9975	8.9933	9.9997		
Max	1.0005	2.0016	3.0026	4.0024	5.0049	6.0035	7.0081	8.0059	9.0067	10.0078		
Min	0.9981	1.9980	2.9970	3.9976	4.9956	5.9945	6.9943	7.9937	8.9917	9.9910		
Range	0.0020	0.0036	0.0056	0.0067	0.0093	0.0138	0.0138	0.0133	0.0150	0.0168		
Sigma	0.0051	0.0091	0.0150	0.0153	0.0252	0.0304	0.0343	0.0345	0.0408	0.0382		
Pp	0.6380	0.7157	0.8521	0.8521	0.6476	0.6452	0.6668	0.7573	0.6058	0.8549		
Ppk	0.5297	0.6580	0.6072	0.8422	0.5410	0.5273	0.6476	0.7326	0.5619	0.8521		
76	0.9992	2.0010	3.0029	4.0024	4.9983	6.0046	6.9965	7.9946	8.9989	10.0073	12/12/94	12:00:00 PM
77	0.9994	1.9993	2.9978	3.9976	4.9986	5.9993	6.9989	7.9987	8.9977	10.0048	12/12/94	12:00:00 PM
78	0.9993	2.0007	2.9996	3.9994	4.9979	6.0028	6.9993	7.9975	9.0037	9.9996	12/12/94	12:00:00 PM
79	0.9997	2.0004	2.9987	4.0011	5.0001	6.0003	6.9990	7.9992	8.9956	9.9983	12/12/94	12:00:00 PM
80	1.0005	1.9995	2.9984	3.9991	4.9956	6.0011	6.9957	7.9934	8.9987	9.9969	12/12/94	12:00:00 PM
81	1.0009	2.0002	3.0009	4.0020	4.9957	6.0029	7.0081	7.9993	8.9921	9.9939	12/12/94	12:00:00 PM
82	1.0004	1.9996	3.0017	4.0020	5.0028	6.0016	7.0007	7.9997	8.9916	10.0041	12/12/94	12:00:00 PM
83	1.0001	1.9997	3.0012	3.9994	4.9996	5.9985	6.9961	8.0029	8.9951	9.9961	12/12/94	12:00:00 PM
84	0.9992	1.9996	2.9999	3.9999	4.9973	6.0029	6.9960	7.9945	9.0067	10.0022	12/12/94	12:00:00 PM
85	0.9989	1.9985	3.0024	4.0001	5.0049	6.0006	7.0068	8.0033	9.0056	10.0028	12/12/94	12:00:00 PM
86	1.0003	2.0002	2.9981	4.0002	5.0003	6.0009	7.0004	8.0018	9.0064	10.0052	12/12/94	12:00:00 PM
87	0.9998	2.0003	3.0009	3.9992	5.0006	6.0033	6.9984	8.0016	9.0077	9.9996	12/12/94	12:00:00 PM
88	0.9996	1.9998	2.9999	3.9990	4.9977	5.9974	6.9997	8.0051	8.9935	9.9990	12/12/94	12:00:00 PM
89	0.9996	1.9991	3.0006	3.9998	5.0043	6.0002	6.9989	8.0017	9.0014	9.9948	12/12/94	12:00:00 PM
90	0.9998	2.0000	2.9985	3.9996	4.9960	5.9995	6.9988	7.9996	8.9970	9.9984	12/12/94	12:00:00 PM
91	1.0005	2.0007	3.0011	4.0017	5.0003	6.0029	6.9968	8.0011	9.0043	10.0040	12/12/94	12:00:00 PM
92	0.9993	2.0004	3.0010	3.9973	4.9981	5.9945	7.0006	8.0029	8.9967	9.9955	12/12/94	12:00:00 PM
93	1.0000	2.0008	3.0005	4.0007	4.9966	6.0063	7.0009	8.0030	8.9956	10.0042	12/12/94	12:00:00 PM