This White Paper explains how to control the formatting of numbers within a report in general and gives step-by-step directions for a changing the formatting for a First Article report.

### **General Number Formatting**

When QC-CALC sends numbers to the reports those numbers have the full 7 digits of precision included. In most cases, you do not want to see that much precision and the templates were set up by default to follow the precision you chose for specific dimensions. This section is going to explain formatting a hard-coded 4 decimal places number, a number without a decimal point at all, and a number that will use the number of decimal places defined for the specific Dimension being processed at the time.

The function that is used to format numbers within the Report Designer is "FStr\$([value],[format to follow])". All examples below will use this function, but the "format to follow" will be different for each.

In each example there will be 7 places to the left of the decimal point reserved. If you do not reserve enough space to the left of the decimal to hold your number you will see a "\*\*\*\*\*\*\*" in your report. Add more spaces to the left and that should fix that issue. The example below shows the "Actual" being sent and 7 places to the left of the decimal and none to the right being reserved to show that number.

```
FStr$(Actual, "----&.")
```

The following items are commonly used in the FStr\$ line:

-	Digit or sign, if negative
+	Digit or sign
#	Digit or space prefix
&	Digit or '0'
	Decimal point

- 1. If a negative number is encountered, the negative sign will not be displayed. For example, "-1.3456" would end up displayed as "1.3456", which is very wrong.
- 2. If a number between 0 and 1 is encountered it will be displayed as ".1234" instead of the "0.1234" you would probably prefer.

### **4 Decimal Places**

For this example we're going to set the format function to always show 4 decimal places to the right of the decimal point along with the 7 places to the left.

FStr\$(Actual, "----&.####") -> 8.1234

#### **No Decimal Places**

For this example we're going to set the format function to always not show any numbers to the right or a decimal point.

```
FStr$(Actual, "----&") -> 8
```

#### **Dynamic Decimal Places**

For this example we're going to set the format function to show the number of decimal places set within the QC-CALC and passed in to the template in the "Precision" variable in this case.

FStr\$(Actual,"-----&."+Rep\$("#",Precision)) -> 8.12345 (with Precision = 5)

For this example, we are using the "Rep\$" (repeat) function to repeat the # character the number of times specified by the precision. This means if your decimal precision was set to 5 in QC-CALC, then the formatting line would be equivalent to:

FStr\$(Actual, "----&.#####")

### **First Article Example**

The directions shown here will walk you through changing the formatting of the numbers in the Nominal column in the data area of the table of a First Article report.

- From QC-CALC Real-Time choose the Report > Design Template menu as shown to the right.
- 2. Choose the OnePiece.FST template from the list of files that appears and click **Open**.
- 3. The Report Designer now appears on the screen.







4. Use the Objects area in the upper left area of the screen and double-click on the "Table 1" item.



5. In the **Table Contents** window that appears, choose the **Data Line** tab at the top and then double-click the "Nominal" line in the **Line Definition 1** area.

▲ 🎦 🛨 🖂 🔀 🖬 🖷 ↑ ↓	🔠 👌 [+] 🌟 Search Prop	perties 🔻 🖲
<ul> <li>Line Definition 1</li> <li>Ai if(@User03," ",fstr\$(Char_Number,'#####"))</li> <li>Ai if(StrPos(Char_Label,"?")=-1,Char_Label,Left\$(</li> <li>A ""</li> <li>Ai if(Upper\$(Char_Source)="P/F", ",FStr\$(Nomine)</li> <li>Ai if(Upper\$(Char_Source)="P/F", ",if(Plus_Toler)</li> <li>Ai if(Upper\$(Char_Source)="P/F", ",if(Minus_Tole)</li> <li>"</li> <li>Ai if(Upper\$(Char_Source)="P/F", ",if(Actual=0,"FA)</li> <li>Ai if(Upper\$(Char_Source)="P/F", ",Fstr\$(Actual=0,"FA)</li> <li>Ai if(Upper\$(Char_Source)="P/F", if(Actual=0,"FA)</li> <li>Ai if(Upper\$(Char_Source)="P/F", ", ", # If(Plus_Toler)</li> <li>Ai if(Upper\$(Char_Source)="P/F", ", ", # If(Plus_Toler)</li> <li>Ai if(Upper\$(Char_Source)="P/F", ", ", # If(Plus_Toler)</li> <li>Ai if(Upper\$(Char_Source)="P/F", ", # If(Plus_Toler)</li> <li>Ai if(@User03, fstr\$(Char_Number, '#####')," ")</li> <li>A "Bonus"</li> </ul>	<ul> <li>Design Name</li> <li>Data (Contents) Options</li> <li>Appearance</li> <li>Background Conditional Formatting Export as Picture</li> <li>Font Format</li> <li>Preview Animation Rotation Text Format</li> <li>Action Link URL</li> </ul>	if(Upper\$(Char_Source Transparent <not set=""> No [Arial, 9.0 pt] None 0° Normal Text</not>
	Design	Ŷ

6. In the **Edit Table** window that appears, you will see the FStr\$ as the 2<sup>nd</sup> half of the line in the bottom section of the window. Currently the Dynamic formatting method is being used, but we're going to switch it to a hard-coded 5 decimal places instead.

Edit Table		
Data and Functions Condition Text Da	te Format Number Format Operators Colors	
Search Variables/Fields	✓ Functions:	
> 🔂 Variables	Search Term or Function Name	
> 📅 Fields > 👔 User variables	>       Numerical functions     >       Mathematical functions      Date functions	
	String functions     Project and print dependent functions     Misc. functions	
		Insert
if(Upper\$(Char_Source)="P/F"," "FStr	\$(Nominal, "&." + Rep\$("#", Precision)))	(⇔) (
		ΣΣ
		믹
		<u>ا</u> ا
111		• • e
16.0000		
a 🚍	OK	Cancel

- 7. Remove the +Rep\$("#",Precision) section at the end of the line, but make sure you leave 2 ")" at the end.
- 8. Now, to hard-code the 5 decimal places, type ###### between the . and the ".
- 9. The line you end up with should be:

if(Upper\$(Char_Source)= "P/F", " "FStr\$(Nominal, "&,#####"))		(⇔)	()
		$\Sigma_{\Sigma}$	25
			4
			<b>গ</b> ≣
4		ۍ ا	¢
16.00000			
	<u>о</u> к	Cancel	

- 10. Click **OK** in the **Edit Table** and **Table Contents** windows, then choose **File** > **Save** to save your changes.
- 11. Now when you run that report you should always see 5 decimal places for the Nominal regardless of the precision set for each dimension.